

Part two in a series of how to read your Mustang warranty plate. Any questions? Contact Jon Whittington, 106 South Urbana, Urbana, Illinois 61801.

1964 $\frac{1}{2}$ -1973 MUSTANG ENGINE CODES (Includes Boss and Shelby)

CODE	1964 $\frac{1}{2}$	1965	1966	1967	1968	1969	1970	1971	1972	1973
A		289-4V	289-4V	289-4V						
C		289-2V	289-2V	289-2V	289-2V			429-4V		
D	289-4V									
F	260-2V				302-2V	302-2V	302-2V	302-2V	302-2V	302-2V
G						302-4V BOSS	302-4V BOSS			
H						351-2V	351-2V	351-2V	351-2V RAMAIR	351-2V RAMAIR
J					302-4V			429-4V RAMAIR		
K	289-4V HI-PO	289-4V HI-PO	289-4V HI-PO	289-4V HI-PO						
L						250-1V	250-1V	250-1V	250-1V	250-1V
M						351-4V	351-4V	351-4V		
Q						428-4V	428-4V	351-4V RAMAIR	351-4V	351-4V
R					428-4V RAMAIR	428-4V RAMAIR	428-4V RAMAIR	351-4V BOSS	351-4V HO	
S				390-4V	390-4V 428-4V	390-4V				
T		299-1V	200-1V	200-1V	200-1V	200-1V	200-1V			
U	170-1V									
W					7-4V					
X					390-2V	390-2V				
Z						429-4V BOSS	429-4V BOSS			
2				289-4V GT-350						
4				428-8V GT-500						

*denotes 390-4V in Mustangs and 428-4V in Shelbys.